


FIG. 1















FIG. 4

















FIG. 13






FIG. 14





ATE	
INITIAL ST	
DS1/E1 CHANNEL INITIAL STATE	
DS1/E1 LABEL	
CIC EC LABEL IWU LABEL IWU PORT	
IWU LABEL	
EC LABEL	
GROUP MEMBER	
TRUNK GROUP NUMBER GROUP MEMBER	

INITIAL STATE	
RECEIVE VPI INITIAL STAT	
1	
TRANSMIT VPI	
NG TRANSMIT INTERFACE TRANSMIT LABEL	
STARTIN	
GROUP	
TRUNK GROUP NUMBER GROUP SIZE	

## FIĞ. 19

L								
RUNK GROUP NUMBER	ADMIN	ASSOCIATED	CLLI	TRUNK	CLLI   TRUNK   ASSOCIATED   ASSOCIATED	ASSOCIATED	TIME	ЕСНО
	INFORMATION	POINT CODE		TYPE	NPA	٩Ŋ	ZONE	CANCELLER
					-		LABEL	INFORMATION

# FIG. 20A

SATELLITE	SELECT	NMI	GLARE	CONTINUITY	CONTINUITY REATTEMPTS IGNORE LNP		TREATMENT	MESSAGE
	SEQUENCE	PRIORITY	RESOLUTION	CONTROL		INFORMATION	LABEL	MAPPING LABEL
							٠	

# FIG. 20B

	_	_
NEXT LABEL		
ORIGINATING TERMINATING CALL CONTROL NEXT FUNCTION NEXT LABEL COS LABEL COS LABEL		
CALL CONTROL		
TERMINATING COS LABEL		
ORIGINATING COS LABEL	_	
VOICE PATH CUT THROUGH		
QUEUE RING NO ANSWER		
QUEUE		

# FIG. 20C

NEXT LABEL	
NEXT FUNCTION	
CARRIER SELECTION	
CARRIER ID	
CARRIER LABEL	

<b>-</b>	بے	
NEXT	LABEL	
NEXT	FUNCTION	
	DIGITS TO	
CALLED NUMBER	DIGITS FROM	
CALLE	NATURE OF ADDRESS	
CALLING PARTY'S	CATEGORY	
EXCEPTION	LABEL	

### FIG. 22

	_	
NEXT LABEL		
NEXT FUNCTION		
ORIGINATION LINE INFORMATION		
OLI LABEL		

### FIG. 23

NEXT	LABEL	
NEXT	FUNCTION LABEL	
QUEUE TREATMENT	LABEL	
QUEUE		
EC	INFORMATION INFORMATION	
TIME ZONE   CUSTOMER	INFORMATION	
TIME ZONE	LABEL	
PARTY NUMBER	OT STIDIO	
CHARGE CALLING PARTY	DIGITS FROM	
ANI	LABEL	

## FIG. 24

MBER	CALLEI	CALLED NUMBER		DELETE	NEXT	NEXT
ABEL	NATURE OF ADDRESS	DIGITS FROM	DIGITS TO	DIGITS	FUNCTION	LABEL
				,		

FIG. 25

NEXT	LABEL		NEXT LABEL		NEXT LABEL		NEXT LABEL	,		DAYLIGHT SAVINGS	
NEXT	FUNCTION		NEXT FUNCTION		NEXT FUNCTION		NEXT FUNCTION			DAYL	
JMBER	DIGITS FROM DIGITS TO	FIG. 26	NEXT	FIG. 27	DAY TO	FIG. 28	TIME TO		FIG. 29	UTC OFFSET	
CALLED NUMBER	NATURE OF ADDRESS DI		DATE		DAY FROM		TIME FROM				
CALLED NUMBER	LABEL		DAY OF YEAR LABEL		DAY OF WEEK		TIME OF DAY LABEL			TIME ZONE LABEI	-

FIG. 30

SIGNAL ROUTE LABEL		
NEXT LABEL		The state of the s
NEXT FUNCTION		
ROUTE NUMBER		
ROUTING LABEL		

FIG. 31

		]
NEXT LABEL		
NEXT FUNCTION		
TERMINATING TRUNK COS LABEL		
ORIGINATING TRUNK COS LABEL		

FIG. 32

_	_	
NEXT LABEL		
NEXT FUNCTION		
ERROR/CAUSE LABEL		
TREATMENT LABEL		

FIG. 33

	CAUSE VALUE	
OUTGOING CAUSE VALUE	CODING STANDARD	
	LOCATION	
OUTGOING RELEASE	LABEL	

FIG. 34

PASSED	NEXT LABEL	
PAS	NEXT FUNCTION	
ROL	NEXT LABEL	
CONTROL	NEXT FUNCTION	
CONTROL	PERCENTAGE	
PERCENT	LABEL	

FIG. 35

PASSED	NEXT LABEL		
PAS	NEXT FUNCTION		
TROL	NEXT LABEL	·	
CONTROL	NEXT FUNCTION		
CALL	RATE		
CALL RATE	LABEL		

FIG. 37

SCCP LABEL MESSAGE TYPE PROTOCOL CLASS MESSAGE HANDLING HOP COUNTER						
	AΒ	MESSAGE TYPE	PROTOCOL CLASS	MESSAGE HANDLING	HOP COUNTER	SEGMENTATION

FIG. 38A

	LABEL	
	MARK INDICATOR	
INSI	ROUTE INDICATOR	٠
	ISNI TYPE	

FIG. 38B

CALLED PARTY ADDRESS	ADDRESS INDICATOR SUB POINT GLOBAL TITLE	GLOBAL TITLE ROUTING NATIONAL/ SYSTEM CODE TRANSLATION ENCODE NUMBER ADDRESS	INDICATOR INDICATOR INTERNATIONAL NUMBER NUMBER TYPE SCHEME PLAN TYPE		
C)	ADDRESS INDICATOR	GLOBAL TITLE ROUTING N	INDICATOR INDICATOR INTE	-	
		POINT	CODE		
		SSN			

FIG. 38C

		ADDRESS	TYPF		
	TITIE	NUMBER	PLAN		
	GLOBAL TITI F	ENCODE	SCHEME		
		TRANSLATION	TYPE SCHEME PLAN	1	
SS	POINT	CODE	NUMBER		
Y ADDRE	SUB POINT	SYSTEM	NUMBER		
CALLING PARTY ADDRESS	CALLING PAR	NATIONAL/ SYSTEM CODE TRANSLATION ENCODE NUMBER ADDRESS	ATOR INTERNATIONAL NUMBER NUMBER		
	ATOR	ROUTING	INDICATOR		
	ADDRESS INDIC	GLOBAL TITLE ROUT	INDICATOR INDICA		
			CODE		
		SSN			

FIG. 38D

NETWORK 16		
NETWORK		
NETWORK 3	-	
NETWORK 2		
NETWORK 1		
ISNI LABEL		T

MESSAGE TYPE		
COMPONENT TYPE		
PACKAGE TYPE		
TAG CLASS		
TCAP TYPE		
TCAP LABEL		

#### FIG. 40

		•	
MODUI F	RS-232 ADDRESS	ECHO CANCELLER TYPE	ECHO CANCELLER LABEL

#### FIG. 41

IWU LABEL	al NMI	IP SOCKET 1	IP SOCKET 2	IP SOCKET 3	IP SOCKET 4

#### FIG. 42

_	Т	_
LOGICAL INTERFACE		
CAM LABEL		
CAM INTERFACE LABEL		

RESS		CALL PROCESSOR ID		ACL 3 ABATE		BILLING FAILURE FREE CALL			
CAM ADDRESS				ACL 3 ONSET		NWM ALLOW		MAX TABLE LOOKUPS	
-		SOFTWARE ID		ACL 2 ABATE		BILLING ACTIVE		MAX	
CAM TYPE	FIG. 44	ORIGINATION ID	FIG. 45A	ACL 2 ONSET	FIG. 45B	RING NO ANSWER TIMER	FIG. 45C		
	-	SITE NODE ID		ACL 1 ABATE		ОНО ТО2		INTS	
CAM LABEL				ACL 1 ONSET	•	ОНО ТО1		MAX HOP COUNTS	
CA		OFFICE CLLI NAME		ACC ENABLED		MAX TRUNKS OHQ			

FIG. 45D

AIN EVENT PARAMETERS LABEL	MESSAGE NAME #1	MESSAGE NAME #	MESSAGE NAME #N
ACCESS CODE			
ACG ENCOUNTERED			
ALTERNATE BILLING INDICATOR	· · · · · · · · · · · · · · · · · · ·		
ALTERNATE TRUNK GROUP			
AMA ALTERNATE BILLING NUMBER			
AMA BUSINESS CUSTOMER ID			
AMA DIGITS DIALED WC	-		: :
AMA LINE NUMBER			
AMA SLPID			
AMP			
ANSWER INDICATOR			
BEARER CAPABILITY			
BUSY CAUSE		,	
CALLED PARTY ID		-	
CALLED PARTY STATION TYPE			
CALLING PARTY BGID			
CARRIER			
CHARGE NUMBER		-	
CHARGE PARTY STATION TYPE			
CLEAR CAUSE	-		
COLLECTED ADDRESS INFORMATION			
COLLECTED ADDRESS INFORMATION	, .		
CONTROLLING LEG TREATMENT	<del>                                   </del>		
DISCONNECT FLAG			<u>-</u>
DISPLAY TEXT			7
FACILITY GID (TRUNK GROUP ID)		<u> </u>	
FACILITY GID (TRONK GROOP ID)			
FACILITY GID (PRIVATE PACILITY GID)			
	-		
FACILITY MEMBER ID FAILURE CAUSE	<u> </u>		
GENERIC NAME			
ISDN INTERFACE ID LATA	1		
ORIGINAL CALLED PARTY ID	<u>                                     </u>		· · · · · · · · · · · · · · · · · · ·
OUTPULSE NUMBER		<del>-</del>	
OVERFLOW BILLING NUMBER			
OVERFLOW BILLING NUMBER			i
PASSIVE LEG TREATMENT			
PRIMARY BILLING INDICATOR			
PRIMARY CARRIER			
PRIMARY TRUNK GROUP			
REDIRECTING PARTY ID			
REDIRECTION INFORMATION			
RESOURCE TYPE			
SECOND ALTERNATE BILLING INDICATOR			
SECOND ALTERNATE CARRIER			
SECOND ALTERNATE TRUNK GROUP			
SPID			
STR PARAMETER BLOCK			

AIN EVENT PARAMETERS LABEL	MESSAGE NAME #1	MESSAGE NAME #	MESSAGE NAME #N
TCM			
TRIGGER CRITERIA TYPE			
USER ID			
VERTICAL SERVICE CODE			
APPLICATION ERROR STRING			
ERROR CAUSE			
FAILED MESSAGE			
CONNECT TIME	·		
CONTROL CAUSE INDICATOR			
ECHO DATA			
FACILITY STATUS			
GAP DURATION			
GAP INTERVAL (NATIONAL GAP INTERVAL)			
GAP INTERVAL (PRIVATE GAP INTERVAL)			
GLOBAL TITLE VALUE	•		
MONITOR TIME			
STATUS CAUSE	_		
TERMINATION INDICATOR		-	
TRANSLATION TYPE		·	
TRIGGER CRITERIA FLAG			

FIG. 46B

MESSAGE TYPE	PARAMETERS	INDEX #1	INDEX #	INDEX #N
ADDRESS COMPLETE	BACKWARD CALL INDICATOR			
	ACCESS TRANSPORT			
	CAUSE INDICATOR	-		
	PRIVATE OPTIONAL			
ANSWER	ACCESS TRANSPORT			
	BACKWARD CALL INDICATOR			
	PRIVATE OPTIONAL			
CALL PROGRESS	NOTIFICATION			
	BACKWARD CALL INDICATOR		<u> </u>	
	ACCESS TRANSPORT			
	CAUSE INDICATOR			
	BACKWARD CALL INDICATOR			
CIRCUIT VALIDATION RESPONSE MESSAGE	CIRCUIT ID NAME		·	
	CLLI CODE			
CONTINUITY	CONTINUITY INDICATOR			
EXIT	DISPOSITION			
	TRUNK GROUP NUMBER			
	SEND BACK EXIT MESSAGE			
INITIAL ADDRESS	FORWARD CALL INDICATOR			
	CALLING PARTY'S CATEGORY			
	GENERIC ADDRESS PARAMETER (LNP)			
	CALLED PARTY NUMBER			
	CALLING PARTY NUMBER			
	GENERIC DIGITS			
	CHARGE NUMBER			
	ORIGINATING LINE INFORMATION			
	TRANSIT NETWORK SELECTION			
	CARRIER SELECTION INFORMATION			
	ORIGINATING LINE INFORMATION			
	SERVICE CODE			
	CARRIER IDENTIFICATION			
	ORIGINAL CALLED NUMBER			
	REDIRECTING NUMBER			
	REDIRECTION INFORMATION			
	GENERIC ADDRESS (NON-LNP)			
	ACCESS TRANSPORT			
	HOP COUNTER			<del></del>
	JURISDICTION INFORMATION			
RELEASE	ACCESS TRANSPORT			
	AUTOMATIC CONGESTION CONTROL			